

Operation Protocols (BarGunCleaner.com)

The **Sea~Gun** is designed so each bar gun remains in its Antimicrobial **Holster Assembly** after each use at all times, perched loosely for quick-draw release.

The parts of the **Sea~Gun** are not to be tampered with by bartenders so as to prevent Cross Contamination or to nullify warranty.

Each bar gun rests in its **Santoprene Collar** (preventing insect penetration) rimming its **Holster**, which is affixed to the bar top by its **Flange**.

UPON CLOSING BAR AT END OF DAILY OPERATIONS

Press each thumb firmly on top edges of each bar gun Applying Force and Squeezing Trigger to a TIGHT FIT, till the bar gun cap sits securely in **Collar**, poised directly over the stainless steel sprayer in **Holster**.

All residues and sugars from every crevice of each bar gun will be removed overnight, triggered by the **Programmable Timer** inside the **DEMA Circulator** as directed by Bar Manager.